


instamagic

FAST HAIR STRAIGHTENER

In mere seconds, this tool evenly distributes heat without damaging your tresses in the process and you control the level of volume.

Plus, it's simpler than ever to use, no clips or fuss, you simply brush your hair—it doesn't get easier than that!





HOW TO USE:

Ensure your hair is dry. Choose your desired temperature. We recommend you begin with 180°C/365°F and change the temperature according to your desire. Use caution while straightening hair to make sure your finger doesn't mistakenly hit the power and temperature buttons located on the side of the brush.

As you apply the brush, ensure your hair penetrates deep into the bristles. You can do this by moderately stretching the hair with the other hand like you would use a regular iron.

Brush slowly to ensure maximum heat is absorbed into the hair. Straighten from the root to the end of your hair in a slow pulling motion. You can use the brush on the inner or outer side of your hair. Do not brush too much hair at once, if you want to brush more hair you should slow down the speed of brushing in the process.

If you straighten your hair often we recommend you use some type of thermal heat protection spray (sold separately). To reduce frizz, we recommend using an oil-based conditioner.

The InstaMagic Hair Straightener is safe to use for all types of hair; including chemically-treated, permed and colored hair.

HOW TO CLEAN THE BRUSH:

Begin by turning the iron off and unplugging it. While it is still warm, moisten a cloth with water. You want it to be wet, but not dripping. Rub the moist cloth over the surfaces to remove as much of the buildup as possible. To remove the remaining residue, spray an iron cleaner (not included) onto the surfaces. Wipe it clean with a clean, soft cloth. Follow this with a cloth moistened with water. Repeat as necessary. Allow the iron to dry completely before plugging it back in to use.

Questions or comments?

Visit www.hairstraightenr.com

instamagic